

COLTIVATORI A MOLLE



CM-LM

CM-LM 5080 HP

DI RAIMONDO

CM-LM

1

????

???	?????	?????	??	???	??????	??	??
	TIPO	CM	CM	CM	CM	KG	HP
CM-7LM		190	27,5	190	25	340	60
CM-7/9LM	MANUALE	187	26,5	239	25	460	70
CM-9LM		228	25	228	25	430	70

CM-9/11LM	MANUALE	228	25	278	25	550	80
-----------	---------	-----	----	-----	----	-----	----

???????????

Attacchi Erpice
